

Upgrading Firmware and resetting the phone V1.0

El-Itek

Upgrading Firmware and resetting the phone

This part is to serve as a basic guidance for upgrading firmware and resetting the phone.

- Upgrading Firmware
- Resetting the phone

Upgrading Firmware

To upgrade firmware via 3CX Management Console

- 1, Login 3CX Management Console -> phone
- 2, Chose the phone which you want to upgrading firmware. The phone must be

Provisioned by 3CX phone system before.

3, Click the **firmware** button. You will see the popover as following picture.

Upgrad	le firmware			k
The belov times.	w IP Phones will be	e upgraded to the lates	t firmware version. The pł	nones will be unavailable during the upgrade and might reboot several
	Model	Device Version	Available Version	Information
	Htek UC923	2.0.4.2.17	2.0.4.2.19	Htek UC923 FW: New Model. Latest SP5 template is required
				OK Cancel

4, Click the **OK** button. Then the phone will restart and upgrade firmware.

Manual upgrading firmware

1, Visit the official Htek website, go to Support and press Download to latest Firmware for IP Phone. From the provided list choose the htek .txt file url



with the latest FW.

2, Download the desired FW image .zip file and extract it on your hard disk.

3, Locate the folder where holds the Htek firmware on 3CX phone system.

Please refer my folder path.

; (C:) 🕨 ProgramData 🕨 3CX 🕨	Instance1 🕨 Data	▶ Http ▶ Interface	 provision 	ing 🕨 459hzrzo1p3i5	▶ firmware ▶ htek
帮助(<u>H</u>)					
▼ 新建文件夹					
名称	修改日期	类型	大小		
📄 fw923.rom	2017/4/27 8:30	ROM 文件	11,695 KB		

4, Copy the rom files to the folder.

5, Restart the phones.

After you upgrade this firmware by this way. If you found the red font on 3CX Management Console as the following picture prompts 3CX don't support this version.

Don't worry, it just means the 3CX still not support this version yet. 3CX may release this firmware very soon. And the version also can support all of features of 3CX.

Resetting the phone

Reset the phone to factory configurations after you have tried all troubles-Hooting suggestions but do not solve the problem. You need to note that all customized settings will be overwritten after reset.

El-Itek

To reset the phone via phone user interface(LCD):

1, Press Menu ->Settings ->Advanced ->Settings ->Reset

The password of Advanced is provisioned by 3CX phone system.

2, Press the Enter softkey or OK key.



3, Press **OK** softkey.

The phone will be reset to factory settings sucessfully after startup.

Note: Reset of your phone may take a few minutes. Do not power off until

the phone has started up successful.